







## **SPECIFICATIONS**

DOT SIZE	3 MOA	6 MOA
DOT COLOR	Bright Red	Bright Red
BATTERY TYPE	CR2032	CR2032
BATTERY RUN TIME (@ SETTING 6)	20,000 hrs.	20,000 hrs.
ILLUMINATION SETTINGS	12 Settings (10 Daylight, 2 NV)	12 Settings (10 Daylight, 2 NV)
EYE RELIEF	Unlimited	Unlimited
MAGNIFICATION	1x	1x
ADJUSTMENT GRADUATION	1 MOA	1 MOA
TRAVEL PER ROTATION	40 MOA	40 MOA
MAX ELEVATION ADJUSTMENT	150 MOA	150 MOA
MAX WINDAGE ADJUSTMENT	150 MOA	150 MOA
PARALLAX SETTING	Parallax Free	Parallax Free







WIDTH	1.27"
HEIGHT	1.20"
LENGTH	1.84"
WEIGHT (W/ BATTERY)	1.75 oz.
MOUNTING FOOTPRINT	DeltaPoint® Pro



## VENOM® ENCLOSED MICRO RED DOTS

For those seeking reliable performance and functionality no matter how tough the conditions, the Venom® Enclosed Micro Red Dot features an easy-to-mount, closed design that shields against disruptions from rain, dust, or snow. With a large sight window, motion activation, and adjustable brightness, it delivers function, handling, speed, and accuracy in any shooting situation.





Images are for representation only. Product may vary slightly from what is shown.



## **BASIC OPERATION**

## **Battery Installation and Replacement**

Remove the Battery Cap using the side of the included Custom Tool. Install one CR2032 battery so the "+" lettering faces out and replace the cover. When replacing the Battery Cap, be sure it is fully tightened utilizing the side of the included Custom Tool.

**Note:** Upon first use, remove the battery isolator from under the battery.

## **Power Up**

To turn the Venom® on, press either the "+" or "-" button. To turn off the Venom® manually, press and hold the "-" button for approximately five seconds.

#### **Auto-Shutoff**

The red dot will automatically shut off after 10 minutes. To turn on the Auto-Shutoff feature, press and hold both the "+" and "-" buttons for three seconds. During these three seconds, the dot will turn on at the lowest brightness setting and gradually increase to the brightest setting. Once the dot has reached its brightest setting, the Auto-Shutoff feature is now on. To disengage Auto-Shutoff, hold "+" and "-" for three seconds. The dot will start at the highest setting and step down to the lowest brightness setting over three seconds.

## Motion Activation

The Venom® is equipped with motion activation. This feature is only available when the Auto-Shutoff feature is turned on. By allowing the unit to shut off automatically after 10 minutes, the dot will turn on automatically the next time you pick up your gun. Powering down the red dot manually will disable the motion activation.

ĥ



#### **Button Lockout**

The Venom® includes a button lockout mode to prevent unintentional setting changes. To turn on the button lockout feature, press and hold the "+" button for three seconds. The dot will blink off for a half second and then remain on. To turn the button lockout feature off, press and hold the "+" button for three seconds. The dot will blink off twice in one second to confirm the lockout mode has been disabled and then will remain on.

## **Brightness Selection**

The Venom® offers 12 brightness settings. 10 daylight settings and two night-vision settings. Adjust the dot brightness by pressing the appropriate "+" or "-" button.

#### **Battery Run Time and Battery Life**

The Venom® uses a CR2032 battery. The battery run time is the actual power draw of the unit compared to the capacity of the battery. Not all batteries have the same output. On average, with the Venom® in constant on mode with the Auto-Shutoff disabled the battery run time at setting six is 20,000 hours.

Battery life is the time measured in-between putting a battery into the unit and having to replace it. This number is a variable based on many different factors including, time used, brightness setting changes, Auto-Shutoff mode engaged etc. While this number is dependent on the user, here are some scenarios:

	Battery Life	
VENOM® SETTING 6 FOR 24 HOURS A DAY	20,000 Hours	833 Days
VENOM® SETTING 6 FOR 12 HOURS A DAY	40,000 Hours	1,667 Days
VENOM® SETTING 6 FOR 8 HOURS A DAY	60,000 Hours	2,500 Days
VENOM® SETTING 6 FOR 6 HOURS A DAY	80,000 Hours	3,333 Days



#### **Turret Adjustments**

Turrets are used to adjust the bullet's point of impact and are marked in Minute of Angle (MOA). There are two turrets on your red dot. The turret on the top of the red dot is the Elevation Turret and is used to adjust the point of impact up and down. The turret on the right-hand side is the Windage Turret and is used to adjust the point of impact left and right.

Your Venom® features adjustable Elevation and Windage Turrets with audible and tactile clicks. Each click moves the bullet's point of impact 1 Minute of Angle. The chart indicates how many inches your bullet's point of impact will move per 1 MOA click at different distances from your target.

DISTANCE IN YARDS	MOVEMENT PER CLICK (INCHES)
10 YDS.	~0.10"
20 YDS.	~0.20"
25 YDS.	~0.25"
30 YDS.	~0.30"
40 YDS.	~0.40"
50 YDS.	~0.50"
75 YDS.	~0.75"
100 YDS.	~1.00"
200 YDS.	~2.00"

**Note:** If not shooting at one of the example distances, use this formula:

(Yardage x .01) x 1.047 = Movement Per Click in Inches



**EXAMPLE:** At a 25-yard sight-in distance, it will take 12 clicks of the turret to move the bullet's point-of-impact three inches.

#### To make turret adjustments:

- 1. Use the included Custom Tool.
- Turn the turret in the appropriate direction: up/down or left/right as indicated by the arrows.

**Note:** The red dot will move in the opposite direction of the turrets when dialed



#### Mounting the Venom® Enclosed Micro Red Dot

To get the best results from your Venom® Enclosed Micro Red Dot, proper mounting is essential. Although not difficult, the correct steps must be followed.

The Venom® utilizes the same screw spacing as the DeltaPoint® Pro footprint and will work on any pistol that is cut for a DeltaPoint® Pro red dot. You may have to reference the pistol's manual to see if any additional plates are required to mount the red dot. If a plate is required, mount the plate using the pistol or plate manufacturer's recommendations.

To install the red dot, on top of the pistol slide or plate matching up the screw holes and recoil lugs. Ensure that the red dot sits flush on the mount. Select the appropriate screw size from the screws included in the box with the Venom®. Tighten down the screws to 15 in-lbs without thread locking compound or 12 in-lbs with non-permanent thread locking compound. Thread locking compound is recommended to ensure the screws do not back out under recoil.

If the screw needed is not included, please contact our Technical Dept at 1-800-4VORTEX.



### SIGHTING IN

After the red dot has been mounted, an initial sight-in at 25 yards is recommended. This should allow for the unit to have enough travel to overcome most alignment issues.

- 1. Following all safe shooting practices, fire a three-shot group as precisely as possible.
- 2. Next, adjust the illuminated dot to match the approximate center of the shot group. Be sure to read Page 10 prior to making adjustments.
- **3.** Carefully, fire another three-shot group and see if the bullet group is centered on the bullseye. This procedure can be repeated as many times as necessary to achieve a perfect zero.

**Note:** When you dial the turrets up, the dot will move down, if you dial down, the dot will move up, if you dial left, the dot will move right, if you dial right, the dot will move left.

### MAINTENANCE AND STORAGE

#### Cleaning

Your Venom® Enclosed Micro Red Dot requires very little routine maintenance other than periodically cleaning the exterior lenses. The optic's exterior may be cleaned by wiping with a soft cloth. When cleaning the lenses, be sure to use products that are specifically designed for use on coated optical lenses.

- Be sure to blow away any dust or grit on the lenses prior to wiping the surfaces.
- Using your breath, or a very small amount of water or pure alcohol, can help remove stubborn dried water spots.



#### Lubrication

All components of the Venom® Enclosed Micro Red Dot are permanently lubricated, so no additional lubricant should be applied.

**Note:** Other than removing the Battery Cap and Rubber Cover, do not attempt to disassemble any components of the Venom® Enclosed Micro Red Dot. Disassembly may void warranty.

## Storage

If possible, avoid storing your red dot in direct sunlight or any very hot location for long periods of time.

## TROUBLESHOOTING

#### **Common Issues**

#### Red Dot Does Not Illuminate

If the red dot does not illuminate, please check the following before returning the red dot for service:

- Is the battery dead? Replace the battery.
- Is the battery installed correctly? Be sure the battery is oriented with the "+" facing away from the unit.
- Is the battery cap loose? Be sure cover is snug and contact points are clean.



#### **Dot Moves Within the Window**

• This is a normal function of any red dot that is parallax free. The placement of the dot within the window does not affect your point of impact. As long as the dot is on the target and zeroed, you will hit your target.

#### **Dot is Blooming**

 An astigmatism may cause the dot to look clustered, linear, or starbursted. Lowering the red dot intensity to an appropriate brightness setting, focusing on the target and not the dot, and keeping both eyes open helps reduce blooming.

#### Dot is Stuck in Bottom of Window or Dot Will Not Move

If the dot is stuck in the bottom of the window, the dot could be mounted backwards.
 The "+" button should be toward the muzzle end when mounted.

#### Red Dot Does Not Line Up with My Iron Sights

• Iron sights are independent of the dot. You can have the iron sights sighted in and the red dot sighted in and they may not line up with one another.

#### **Mounting Screws Coming Loose**

• Check to make sure that the mounting screws were torqued to proper specifications. Torque to 12 in-lbs with thread locking compound or 15 in-lbs without.

#### **Bullets Are Not Grouping**

• Be sure all mount screws are tight. You should not be able to twist or move the red dot in any direction. Many times, problems thought to be with the red dot are actually mount problems.



## **SAFETY AND PRECAUTIONS**

The Venom® Enclosed Micro Red Dot contains a 3V CR2032 battery.

## **AWARNING**

- **INGESTION HAZARD:** this product contains a CR2032, 3V button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **INTERNAL CHEMICAL BURNS** in as little as **2 HOURS**.
- KEEP new and used batteries OUT OF REACH OF CHILDREN.
- SEEK IMMEDIATE MEDICAL ATTENTION if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- If ingested, call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).



- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

## **NOTICE**

#### **Virtual Patent Marking Notice By Vortex Optics**

This product may be protected by patents in the U.S. and elsewhere for Vortex Optics. <a href="http://vtx.legal">http://vtx.legal</a> website is provided to satisfy the virtual patent marking provisions of various jurisdictions including the virtual patent marking provisions of the America Invents Act and provide notice under 35 U.S.C. §287(a). Please visit <a href="http://vtx.legal">http://vtx.legal</a> to view list of products that may be covered by one or more U.S./Foreign patents or published patent applications.



# VIP® WARRANTY OUR UNCONDITIONAL PROMISE TO YOU.

We promise to repair or replace the product. Absolutely free.

- ▶ Unlimited.
- ▶ Unconditional.
- **▶ Lifetime Warranty.**

You do not have to register, save the box, or a receipt for the Warranty to be honored.

Learn more at VortexOptics.com

service@VortexOptics.com • 1-800-4VORTEX

**Note:** The VIP® Warranty does not cover loss, theft, deliberate damage, or cosmetic damage not affecting product performance.

For the most up to date manual visit VortexOptics.com



M-00398-0 © 2024 Vortex Optics ® Registered Trademark and TM Trademark of Vortex Optics. Patent Pending